

95\*210mm

TROUBLESHOOT METHODS

Issue	Troubleshoot method
No misting	1. Check the power supply 2. Check the "Misting hole" to see if the device is pumping air 3. Ensure that the top part of the diffuser is tightened with the bottom by turning it clockwise 4. Ensure that the bottle is tightened into the diffuser head

WARRANTY

Your device comes with limited warranty. Please ensure that you have proof of purchase in case a claim arises. Please note that the warranty is non-transferable.

The following will not be covered under warranty:

- Damage caused by accidents or fire.
- Failure to use device properly.
- If the device is repaired by a non-authorized dealer.
- Third party parts used in the machine.

MAINTAINANCE

The scent diffuser should be cleaned every 1-2 months to ensure optimal performance. To clean the inner workings of the device, please follow these steps:

1. Rotate the upper part of diffuser, and fill rubbing alcohol to the bottle.
2. Install the upper part with bottle to diffuser.
3. Turn on the diffuser and keep working 15 minutes, to ensure alcohol go through the whole device.

Remove the electric cord from the diffuser and keep the diffuser in an upright position. Wipe the device with a damp cloth to remove oil stains and fin-gerprints. Don't use any harsh or abrasive to clean the device.

EQUIPMENT COMPONENT INSTRUCTION

Safety instructions:

1. The diffuser should be used in an upright position always. Do not tilt the diffuser as oil can spill inside and damage the device.
2. Do not use the device with any other power cords. Please use the original power cord that comes with diffuser. Position the power cord to prevent tripping hazard.

REPLACING THE NOZZLE

It is very important that you put the tube into the correct position of the nozzle, otherwise the device will not diffuse scent. Within the nozzle there is a small round tube holder that the tube needs to be firmly secured into. TIP: If you have difficulty to see the tube holder in the nozzle, hold a flashlight into the nozzle to increase visibility.

360°  
AROMATICA  
LUXURIOUS SCENT SURROUNDING

Aro/Slim 2GO  
Scent Diffuser

User Manual

210.00 mm

## SCENT DIFFUSER INTRODUCTION

Our scent diffuser utilizes the latest cold-air diffusion technology which turns any of our hotel-inspired fragrance oil into a dry nano-mist, allowing the scent to stay idle in the air for much longer while providing superior, long-lasting coverage. It uses no water or heat and preserves the therapeutic properties of our fragrance oils without altering their smell.

**Uses advanced atomization technology which makes it residue free and safe for pets, children, artwork, and furniture.**

This model comes with an easy to use remote control.

Item	Height	Width
Diffuser	11.22in	3.34in
Remote Control	3.34in	1.7in

## TECHNICAL FEATURES

Model: Aro/Slim 2GO | Power: 10W | Voltage: 5V 2A | Noise: <38 db  
Coverage: 1,000 sq.ft | Oil bottle capacity: 120ml

- The package includes the diffuser with empty 120mL bottle, remote control, USB cable, adapter and user manual.
- The remote control is designed for convenient adjustment of fragrance concentration levels to suit your preferences, as well as setting the desired operating duration for the device.
- Please follow the instructions set out in this manual and use the device correctly.

## USING GUIDE

**Step 1: Remove Empty Bottle**

- Twist the upper part of the diffuser counter-clockwise to take out the empty bottle.

**Step 2: Add The Fragrance Oil**

- Rotate the bottle counter-clockwise to remove it.
- Fill the bottle with your favorite fragrance.

**Step 3: Reinsert The Bottle And Upper Part**

- Reinsert the upper part of the device.
- Twist clockwise to ensure a tight fit.

**Step 4: Power On The Diffuser**

- Connect the device with the USB-C and adapter.
- Use the remote to turn on the device or hold the large light indicator in the front for 2 seconds.

Please note: in the default settings for the diffuser, it will emit scent for 30 seconds and then pause for 60 seconds. This cycle will continue for 4 hours, after which the device will turn off automatically.

## CHARGING GUIDE

Method 1

Method 2

Method 1: Charge power via type-C cable directly.  
Method 2: Charge power via wireless charging base.

## LIGHT INDICATOR / DEVICE FUNCTION

The pill shaped light indicator on the front of the device works as both a power button and a control for misting and timer settings once the device is turned on.

- In order to turn the device on please press and hold the light indicator for 2 seconds.
- To control the misting and device timer using the light indicator, follow these steps:

**Misting Control:**  
After the device is turned on, use the light indicator to adjust misting settings:

## REMOTE CONTROL

Restore to factory settings (AROMA)

Misting timer settings (L1-L6)

Working timer (1H/4H/8H)

## HOW TO USE REMOTE CONTROL

{ON} Press to turn on device.

{OFF} Press to turn device off.

{AROMA} Press the "AROMA" button while the device is turned on to reset the device to its factory settings.

The settings below determine how long the device will mist before turning off, and this cycle continues until the set time interval is completed:

{L1} The diffuser will emit the scent for 30s, followed by a pause of 60s.  
 {L2} The diffuser will emit the scent for 30s, followed by a pause of 120s.  
 {L3} The diffuser will emit the scent for 30s, followed by a pause of 180s.  
 {L4} The diffuser will emit the scent for 30s, followed by a pause of 240s.  
 {L5} The diffuser will emit the scent for 30s, followed by a pause of 300s.  
 {L6} The diffuser will emit the scent for 30s, followed by a pause of 360s.

Timer setting allows the diffuser to run continuously for a specified period of time and automatically turn off.

{1h} 1 hour  
 {4h} 4 hours  
 {8h} 8 hours

## PRESS SEQUENCE

- Press once:** The diffuser emits scent for 30 seconds, then pauses for 60s.
- Press again:** The diffuser emits scent for 30 seconds, then pauses for 120s.
- Press again:** The diffuser emits scent for 30 seconds, then pauses for 180s.
- Press again:** The diffuser emits scent for 30 seconds, then pauses for 240s.
- Press again:** The diffuser emits scent for 30 seconds, then pauses for 300s.
- Press again:** The diffuser emits scent for 30 seconds, then pauses for 360s.

## TIMER SETTINGS:

To adjust the timer setting, use the instructions below, this setting allows the device to cycle through the misting setting for an extended period of time until the device automatically powers off.

- Press twice for 1 hour timer:** The first small LED light below the larger indicator light will power up.
- Press twice for 2 hour timer:** The first and second small LED lights below the larger indicator light will power up.
- Press twice for 4 hour timer:** The first, second, and third small LED lights below the larger indicator light will power up.
- Press twice for 8 hour timer:** The first, second, and third and fourth small LED lights below the larger indicator light will power up.
- Press twice for cancel timer:** All four small LED below the larger indicator light will power off.